Index

Windows 95 / 98

Symbols

100BASE-TX 15
10BASE-T 15

A

ABS Screening 105
activate the RISO Console 96
Add manually 98
Add Printer 97
Add/Modify printer 97
Adobe Type Manager 30
AdobePS 26
AppleTalk Zone 18, 20, 104
ATM 30
Available font cache 46
Available printer memory 46

B

Bitmap (Type3) format 45
Bitmap Spooling 106

C

Cable Recommendations 14
[Capture Settings] Tab 36
CE fonts 33
Comment 98
Communication Settings 103
[Communication Settings] window 20
Configuring System Hardware 7
Configuring the SC7700 Identity on PCs . 96, 97
[Conflict] dialog box 47
[Control] menu 103, 105
crossover Ethernet cable 17
Customizing the Communication Configuration 96, 103
Customizing the Font Configuration in the SC7700 ..... 96, 99
Customizing the Initial Operation Environment 96
Customizing the Printer Driver 36
Cylinder (Drum) Size 47

D

Dark Shades 105
[Details] Tab 36, 40
[Device Options] Tab 38, 46
Download Fonts 100

E

ERROR indicator 12
Ethernet cable 17
EtherTalk 18, 104

F

Factory Settings 111
[File] menu 97
Font Management 99
Font Sample Page 102
Font Substitution Table 43
[Fonts] Tab 37, 43
FUNCTION button 12

G

Gateway Address 18, 104
[Graphics] Tab 37

H

Hold Queue 28

I

Image Control Range 105
Initial Operation Environment 105
Initializing the system 109
Installable Options 46
Installing PS Screen Fonts 32
Installing the ATM 30
Installing the Printer Driver 26
Installing the Utility Tool Programs 22
Interface Specifications 113
IP Address 18, 98, 104

J

Job timeout 48, 106

L

Light Shades 105
local printer 16, 27, 28
Location ID 19, 98
location ID assignment 24

M

Main Power Switch 13
Memory 47
[Monitoring] menu 99, 102

N

NetBIOS 104
Netmask Address 18, 104
network 17
Network Port 13, 114
Network Printer 27
Normal Queue 28

O

Overall Density 105

P

PAGE STANDBY indicator 12
Paper Size 42
[Paper] Tab 37, 42
Parallel cable 15
Parallel Port 13, 113
port 40
Port Settings 41
PostScript error information 48
PostScript header 48
[PostScript] Tab 38, 48
PostScript timeout values 48
POWER button 12
Power Connector 13
PPD file 22, 28
Print Density 106
Print Density Control 47
Print Sample Pages 102
Print Speed 106
printer driver 26
printer font configuration 99
Printer Name 103
printer port 41
[Printers] window 97
Printing sample pages stored in the SC7700 ..... 96, 102
Printing Settings 105
Prohibition 47
[Properties] dialog box 36

R

READY / DATA indicator 12
Resident Font List 115
Reverse order printing 106
RIP 2
RISO Console 22
RISO Scan 22
RISOGRAPH Port 13

S

Safety Guides 8
SC II cable 10
SC7700 Specifications 112
SCII cable 15
Self Test Page 102
self-diagnosis tests 108
Send TrueType fonts to printer 43
Serial cable 15
serial crossover cable 16
Serial Port 13, 113
Serial port setting 16
Settings Page 102
Sorter 47
Spool Settings 41
standard parallel cable 16
START button 12, 108
STOP button 12
straight Ethernet cable 17
System Diagnosis 108

T

TCP/IP 18, 104
TCP/IP addresses 18
Timeout settings 41
Troubleshooting 108
TrueType font 43, 44
TWAIN Driver 22
Type1 44
Type32 46
Type42 45

V

Voltage Selection Switch 9, 13

W

Wait timeout 49, 106
[Watermarks] Tab 38
Workgroup 104

Windows NT 4.0

Symbols

100BASE-TX 15
10BASE-T 15

A

ABS Screening 105
activate the RISO Console 96
Add manually 98
Add Printer 97
Add/Modify printer 97
Adobe Type Manager 64
[Advanced] Tab 69
AppleTalk Zone 18, 20, 104
ASCII 74
ATM 64

B

bidirectional support 70
Binary 75
Bitmap Spooling 106

C

Cable Recommendations 14
Comment 98
Communication Settings 103
[Communication Settings] window 20
Configuring System Hardware 7
Configuring the SC7700 Identity on PCs .. 96, 97
[Conflict] dialog box 75
[Control] menu 103, 105
crossover Ethernet cable 17
CTRL-D 75
Customizing the Communication Configuration 96, 103
Customizing the Font Configuration in the SC7700 ..... 96, 99
Customizing the Initial Operation Environment 96
Customizing the Printer Driver 67
Cylinder (Drum) Size 76

D

Dark Shades 105
[Default Document Properties] dialog box 67
[Device Settings] Tab 68, 74
Document Defaults 67
[Document Properties] dialog box 67
Download Fonts 100

E

ERROR indicator 12
Ethernet cable 17
EtherTalk 18, 104

F

Factory Settings 111
[File] menu 97
Font Management 99
Font Sample Page 102
Font Size 75
Font Substitution Table 74
FUNCTION button 12

G

Gateway Address 18, 104

H

Hold Queue 56

I

Image Control Range 105
Initial Operation Environment 105
Initializing the system 109
Installable Options 75
Installing PS Screen Fonts 66
Installing the ATM 64
Installing TrueType Screen Fonts 66
Interface Specifications 113
IP Address 18, 98, 104

J

Job timeout 75, 106

L

Light Shades 105
local printer 16
Location ID 19, 98
LPR Port 60

M

Main Power Switch 13
Memory 75
[Monitoring] menu 99, 102

N

NetBIOS 104
NetBIOS over TCP/IP 54
Netmask Address 18, 104
network 17
Network Port 13, 114
Normal Queue 56

O

Output Protocol 74
Overall Density 105

P

[Page Setup] Tab 69
PAGE STANDBY indicator 12
Parallel cable 15
Parallel Port 13, 113
[Ports] Tab 67, 70
PostScript Memory 74
POWER button 12
Power Connector 13
Print Density 106
Print Density Control 76
Print Sample Pages 102
Print Speed 106
printer font configuration 99
Printer Name 103
printer pooling 71
printer port 70
[Printers] window 97
Printing sample pages stored in the SC7700 ..... 96, 102
Printing Settings 105
Priority 72
Prohibition 75
Properties 67
[Properties] dialog box 67
PS screen fonts 66

R

READY / DATA indicator 12
Resident Font List 115
Reverse order printing 106
RIP 2
RISOGRAPH Port 13

S

Safety Guides 8
SC II cable 10
[SC7700 Properties] Dialog Box 67
SC7700 Specifications 112
[SC7700... Default Document Properties] Dialog Box 69
[Scheduling] Tab 67, 72
SCII cable 15
[Security] Tab 68
Self Test Page 102
self-diagnosis tests 108
Serial cable 15
serial crossover cable 16
Serial Port 13, 113
Serial port setting 16
Settings Page 102
[Sharing] Tab 68
Sorter 76
Spooling setting 72
standard parallel cable 16
START button 12, 108
STOP button 12
straight Ethernet cable 17
System Diagnosis 108

T

TBCP 75
TCP/IP 18, 104
TCP/IP addresses 18
TCP/IP via LPR Port 54, 60
Troubleshooting 108
TrueType font 75
Type1 75
Type3 75
Type32 75

V

Voltage Selection Switch 9, 13

W

Wait timeout 75, 106
Workgroup 104

Macintosh

Symbols

100BASE-TX 15
10BASE-T 15

A

ABS Screening 105
activate the RISO Console 96
Add manually 98
Add Printer 97
Add/Modify printer 83, 97
Adobe Type Manager 90
AdobePS 84, 86
AppleTalk Zone 18, 20, 104
ATM 90

B

Bitmap Spooling 106

C

Cable Recommendations 14
CE fonts 93
[Chooser] dialog box 86
Comment 98
Communication Settings 103
[Communication Settings] window 20
Configure 88
Configuring System Hardware 7
Configuring the Printer Driver 86
Configuring the SC7700 Identity on PCs .. 96, 97
[Control] menu 103, 105
crossover Ethernet cable 17
Customizing the Communication Configuration 96, 103
Customizing the Font Configuration in the SC7700 ..... 96, 99
Customizing the Initial Operation Environment 96
Cylinder (Drum) Size 88

D

Dark Shades 105
Download Fonts 100

E

ERROR indicator 12
Ethernet cable 17
EtherTalk 18, 104

F

Factory Settings 111
[File] menu 97
Font Management 99
Font Sample Page 102
FUNCTION button 12

G

Gateway Address 18, 104

I

Image Control Range 105
Initial Operation Environment 105
Initializing the system 109
Installing PS/TrueType Screen Fonts 92
Installing the Printer Driver 84
Installing the Utility Tool Programs 80
Interface Specifications 113
IP Address 18, 98, 104

J

Job timeout 106

L

Light Shades 105
local printer 16
Location ID 19, 98
location ID assignment 82

M

Main Power Switch 13
Memory 88
[Monitoring] menu 99, 102

N

NetBIOS 104
Netmask Address 18, 104
network 17
Network Port 13, 114

O

Overall Density 105

P

PAGE STANDBY indicator 12
Parallel cable 15
Parallel Port 13, 113
POWER button 12
Power Connector 13
PPD file 80, 87
Print Density 106
Print Density Control 89
Print Sample Pages 102
Print Speed 106
printer driver 84
printer font configuration 99
Printer Name 103
[Printers] window 97
Printing sample pages stored in the SC7700 ..... 96, 102
Printing Settings 105

R

READY / DATA indicator 12
Resident Font List 115
Reverse order printing 106
RIP 2
RISO Console 80
RISO Scan 80
RISOGRAPH Port 13

S

Safety Guides 8
SC II cable 10
SC7700 Specifications 112
SC7700-direct 87
SC7700-hold 87
SC7700-normal 87
SCII cable 15
Self Test Page 102
self-diagnosis tests 108
Serial cable 15
serial crossover cable 16
Serial Port 13, 113
Serial port setting 16
Settings Page 102
Sorter 89
standard parallel cable 16
START button 12, 108
STOP button 12
straight Ethernet cable 17
System Diagnosis 108

T

TCP/IP 18, 104
TCP/IP addresses 18
Troubleshooting 108
TrueType font 93
TWAIN Driver 80
Type1 93

V

Voltage Selection Switch 9, 13

W

Wait timeout 106
Workgroup 104